


**vonhaus**

# STEEL LOADING RAMP



## Setup Instructions

Product No. 3500320.1

**Need further help?**  
[support@vonhaus.com](mailto:support@vonhaus.com)

**Besoin d'aide supplémentaire ?**  
[support@vonhaus.com](mailto:support@vonhaus.com)

**Benötigen Sie weitere Hilfe?**  
[support@vonhaus.com](mailto:support@vonhaus.com)

**Necesita más ayuda?**  
[support@vonhaus.com](mailto:support@vonhaus.com)

**Hai bisogno di ulteriore assistenza?**  
[support@vonhaus.com](mailto:support@vonhaus.com)

**See our full range at**  
[www.vonhaus.com](http://www.vonhaus.com)

**Découvrez notre gamme complète sur**  
[www.vonhaus.com](http://www.vonhaus.com)

**Entdecken Sie unser gesamtes  
Sortiment auf**  
[www.vonhaus.com](http://www.vonhaus.com)


**Descubra toda nuestra gama en**  
[www.vonhaus.com](http://www.vonhaus.com)

**Scopri tutta la nostra gamma su**  
[www.vonhaus.com](http://www.vonhaus.com)

# Components

---


**A** X2



# Assembly

---


1



2



# Assembly

3





# Folding Up

---





# Do's & Don'ts

---



# Do's & Don'ts



---





# Do's & Don'ts

---



# Information

---

## Preparing to Use

1. Position the ramps on the lip of the tailgate or trailer.
2. Once secure, you're ready to slowly load your machinery.
3. Ensure the loading bed is parallel to the ground with no slope.
4. Secure the vehicle to be loaded:
  - Turn off the engine
  - Engage the gear
  - Apply the parking brake
  - Block wheels with wedges or other effective means

## Positioning the Ramps

- Place ramps parallel to each other and perpendicular to the loading bed.
- Verify the distance between ramps matches the vehicle's wheelbase.
- Ensure ramp heads rest entirely on the loading bed.

## Loading the Vehicle

- Check the ascent trajectory before starting.
- Keep vehicle wheels or tracks centered on the ramps during ascent.
- Do not adjust trajectory during ascent to avoid instability, slipping, falling, or tipping risks.

## Important Safety Notes

- Never use supports to increase ramp load-bearing capacity.
- Avoid driving on ramp edges to prevent accidents.

## After Use

- Remove ramps from the vehicle.
- Close the ramps.
- Lock ramps in the folded position (see page six).

# Information

---

## Health & Safety

- Always ensure the ramps are securely positioned before loading or unloading.
- Do not exceed the maximum load capacity of 400kg.
- Wear appropriate safety gear, including gloves and sturdy footwear.
- Ensure the ramps are free from debris and obstructions before use.
- Regularly inspect the ramps for signs of wear or damage.

## Maintenance

- Regularly inspect the ramps for any signs of wear or damage before use.
- Clean the ramps with a damp cloth to remove dirt and debris.
- Store the ramps in a dry place to prevent rust and corrosion.
- Ensure the ramps are securely positioned before loading or unloading.

## Troubleshooting

### Why is my ramp slipping during use?

- Ensure the ramp is placed on a stable, non-slippery surface.
- Check that the ramp's rubber feet or grip pads are intact and clean.

### How do I secure the ramp to the vehicle?

- Ensure the ramp is aligned properly before loading.

### How can I prevent the ramp from moving during loading?

- Ensure the ramp is on a flat, stable surface.

### What should I do if the ramp is damaged?

- Inspect the ramp for any visible damage or wear.
- Do not use the ramp if it is damaged.
- Contact the manufacturer for repair or replacement options.

### What should I do if the ramp is bending under weight?

- Check the weight limit and ensure you are not exceeding it.
- Distribute the load evenly across the ramp.

## Technical Specifications

**Capacity:** 400kg (200kg per ramp)

# Information

---

## Thank You

Thank you for purchasing your product/appliance.

Should you require assistance with your purchase, please contact us at [support@domu.co.uk](mailto:support@domu.co.uk)

VonHaus is a registered trademark of DOMU Brands Ltd. Made in China for DOMU Brands.

VonHaus is a registered trademark of DOMU Brands Ltd.

Made in China for DOMU Brands.

## Authorised Representative

Authorised Representative Service  
77 Camden Street Lower  
Dublin, D02 XE80, Ireland

## DISPOSAL INFORMATION

Please recycle where facilities exist. Check with your local authority for recycling advice.

## CUSTOMER SERVICE

If you are having difficulty using this product and require support, please contact [support@vonhaus.com](mailto:support@vonhaus.com)

## WARRANTY

To register your product and find out if you qualify for a free extended warranty please go to [www.vonhaus.com/warranty](http://www.vonhaus.com/warranty).

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately.

Any abuse of the product or the manner in which it is used will invalidate the warranty.

## RETURNS

Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

## COPYRIGHT

All material in this instruction manual are copyrighted by DOMU Brands.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.



Product No. 3500320.1